




Installation instructions to install an RIAA pre-amp on your Airlab-DT EQ module.

Instructions:

1. Remove the screw cover strips on top and bottom of the module.
2. Remove all screws from the Tripe EQ module where you want to include a RIAA pre-amp option.
3. Lift the module.
4. Remove the module carefully out of the console and lay down on a soft layer on top of the console.
5. Remove the jumpers on the printed board where you need to place the RIAA option.



6. Connect your purchased RIAA pre-amp option on the printed board. Be careful that you place the RIAA correctly over the male and female headers.



7. Now place the module carefully inside the console.

On this moment the module is ready for pre-amp option on "LINE B" on your module.

8. Test everything before you mount all front panels again.

Good luck!