

AIRENCE CONTROL SECTION

10600805 Jack Break


10550416 WB switch 4 pole  
10450008 Pushbutton white diffused

10550415 Alps Spuj switch 4 pole  
10450208 Pushbutton grey

10550101 Encoder  
10450102 Knob Sifam

10550452 Switch Honyone 12x12 (24x)

20851728 AIRENCE CONTROL  
SMD PCB



AIRENCE MASTER LEFT-smd

10550414 Alps Spuj switch 2 pole

10300423 10KAx2

10550415 Alps Spuj switch 4 pole

10300423 10KAx2

10550415 Alps Spuj switch 4 pole

10550414 Alps Spuj switch 2 pole

10550415 Alps Spuj switch 4 pole

10300423 10KAx2

10450209 Pushbutton black

10300098 K-ALPS fader 2x 10KA log



10450208 Pushbutton grey

10450121 Telco send knob black-red

10450209 Pushbutton black

10450120 Sub send knob black-grey

10450209 Pushbutton black

10450208 Pushbutton grey

10450208 Pushbutton grey

10450121 Telco send knob black-red

20851724 AIRENCE MASTER  
LEFT-PCB smd

10450115 Knob fader black 1.2x8mm

AIRENCE MASTER RIGHT **smd**

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10300423 10KAx2

10550415 Alps Spuj switch 4 pole

10550414 Alps Spuj switch 2 pole

10300423 10KAx2

10550415 Alps Spuj switch 4 pole

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10550415 Alps Spuj switch 4 pole

10550415 Alps Spuj switch 4 pole

10300420 10KBx2 Center Click

10550395 Alps Spun switch 2 pole mom



10450208 Pushbutton grey

10450208 Pushbutton grey

10450121 Studio send knob black-red

10450208 Pushbutton grey

10450208 Pushbutton grey

10450121 Announcer send knob black-red

10450208 Pushbutton grey

10450208 Pushbutton grey

10450208 Pushbutton grey

10450208 Pushbutton grey

10450208 Pushbutton grey

10450121 Telco send knob black-red

10450009 Pushbutton grey

## AIRENCE MASTER CENTER

10550415 Alps Spuj switch 4 pole

10300423 10KAx2

10550415 Alps Spuj switch 4 pole

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10300420 10KBx2 Center Click

10300423 10KAx2



10450209 Pushbutton black

10450121 Telco send knob black-red

10450209 Pushbutton black

10450208 Pushbutton grey

10450208 Pushbutton grey

10450120 Sub send knob black-grey

10550415 Alps Spuj switch 4 pole

10450121 Telco send knob black-red

**20851726 AIRENCE-6 Talkback PCB smd**

# MIC-LINE AIRENCE smd version

Potentiometers part numbers

10300428 10KBx2

10450208 Pushbutton grey

10450208 Pushbutton grey

10300421 100KBx2 centre click

10300421 100KBx2 centre click

10300421 100KBx2 centre click

10450208 Pushbutton grey


10450208 Pushbutton grey

10300423 10KAx2

10450008 Pushbutton white diffused

10450008 Pushbutton white diffused

10300098 K-ALPS fader 2x 10KA log



Switches and knobs

10450121 Gain knob black-red

10550414 Alps Spuj switch 2 pole

10550415 Alps Spuj switch 4 pole

10450120 EQ knob black-grey

10450120 EQ knob black-grey

10450120 EQ knob black-grey

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10450121 Aux knob black-red

10550416 WB switch 4 pole

10550416 WB switch 4 pole

**20851701 AIRENCE-2  
MIC/LINE smd PCB**

10450115 Knob fader black 1.2x8mm

# MIC-LINE-USB AIRENCE smd

Potentiometers part numbers

10300428 10KBx2

10450208 Pushbutton grey

10450208 Pushbutton grey

10300421 100KBx2 centre click

10300421 100KBx2 centre click

10300421 100KBx2 centre click

10450208 Pushbutton grey

10450208 Pushbutton grey

10300423 10KAx2

10450008 Pushbutton white diffused

10450008 Pushbutton white diffused

10300098 K-ALPS fader 2x 10KA log



Switches and knobs

10450121 Gain knob black-red

10550414 Alps Spuj switch 2 pole

10550415 Alps Spuj switch 4 pole

10450120 EQ knob black-grey

10450120 EQ knob black-grey

10450120 EQ knob black-grey

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10450121 Aux knob black-red

10550416 WB switch 4 pole

10550416 WB switch 4 pole

**20851722 AIRENCE-2  
MIC/LINE /USB smd PCB**

10450115 Knob fader black 1.2x8mm

# AIRENCE TELCO SMD VERSION

## Potentiometers part numbers

10300429 100KBx2 Centre click

10450208 Pushbutton grey

10300429 100KBx2 Centre click

10450009 Pushbutton grey

10450009 Pushbutton grey

10450208 Pushbutton grey

10450208 Pushbutton grey

10300423 10KAx2

10450008 Pushbutton white diffused

10450008 Pushbutton white diffused

10300098 K-ALPS fader 2x 10KA log



## Switches and knobs

10450121 Telco send knob black-red

10550414 Alps Spuj switch 2 pole

10450121 Gain knob black-red

10550400 Alps Spun switch 2 pole latching

10550395 Alps Spun switch 2 pole mom

10550414 Alps Spuj switch 2 pole

10550414 Alps Spuj switch 2 pole

10450120 Gain knob black-grey

10550416 WB switch 4 pole

10550416 WB switch 4 pole

## 20851723 AIRENCE TELCO PCB SMD VERSION

10450115 Knob fader black 1.2x8mm